

Template for 2 3/8" Backset 6K and 7KC Cylindrical Locks

Caution: For 7KC ONLY, drill a 5/16" dia. holes in the position shown. To ensure proper alignment of the through-bolts and levers, use a KD303 drill jig. The "C" style rose on the 6K locks will NOT cover these holes.

