



**Notes**

- 1 Attach the strike with #6 x 3/4" FHWS on wood doors.  
Use #6-32 x 1/4" FHMS on metal doors.
- 2 Allow +1/32" tolerance for clearance.

Title Installation Specifications for 2S75 x TBM Push Lock				<b>BEST ACCESS SYSTEMS</b>		
Series 2S	Backset —	Trim style —	Door thickness 7/8" - 1 5/8"	Rev date 08/2002	Template number <b>S14</b>	Rev <b>B</b>