



Notes

- 1 Attach the strike with
#6 \times $\frac{3}{4}$ " FHWS on wood doors.
Use #6-32 \times $\frac{1}{4}$ " FHMS on metal doors.
- 2 Slot through door is
 $\frac{3}{4}$ " \times $1\frac{9}{16}$ ".
- 3 Allow $+\frac{1}{32}$ " tolerance for clearance.

Title Installation Specifications for 2S75 Door Lock					BEST ACCESS SYSTEMS		
Series 2S	Backset —	Trim style —	Door thickness $1\frac{19}{32}$ " - $1\frac{5}{8}$ "	Rev date 04/2000	Template number S07	Rev A	