

verify exactly 1"  
 verify exactly 1"  
 verify exactly 1"

Measure  
 scale after  
 printing

## Left-Hand Door Template

Fold along this line and position at the top of the LH door.

Top of LH door

Fold along this line and position at the top of the LH door.

Hinge side

Tear along this line and position at the hinge edge of the door.

Tear here.

Tear here.

Tear here.

Hinge side

Tear along this line and position at the hinge edge of the door.

Fold along this line and position at the top of the RH door.

Top of RH door

Fold along this line and position at the top of the RH door.

## Right-Hand Door Template

### Track Rail Mounting Template Instructions

Use this template only for doors that open IN (PULL). For doors that open out (push) see the Push Arm Mounting Template, 05132-11.

- 1 Use the *PULL ONLY: Back Plate Mounting Template* to mount the operator. See that template and the *Installation Guide* for complete details.
- 2 Determine the hand of the door. Use only the Left-Hand or Right-Hand Template. Tear out the template that you need and tear or cut off these instructions. This will create an edge that you can use to align the template along the hinge edge of the door.
- 3 Fold the template along the dashed line to create the edge that will align to the top of the door.
- 4 Carefully place the template in position on the door by aligning the fold across the top of the door and along the hinge edge of the door. Tape the template to the door.
- 5 Make sure that the template is level and plumb. Reposition as needed.
- 6 Center punch the drill points.
- 7 Drill and tap the mounting holes. Use a #17 (0.173") or 11/64" dia drill and 12-24 tap for the mounting screws. Remove the template.
- 8 Assemble the main arm to the operator.
- 9 Insert the arm into the track rail and mount the track rail to the door (with the arm already inserted into the track).
- 10 Mount the track rail to the door and connect the arm to the operator. Refer to the *Installation Guide* for complete details.

## D-4990 Low Energy Operator Track Arm Mounting Template

DRWG 05133-11-000 DATE 08/01/07 P/N 204053 A REV PRINT SPEC ER7991-44



**ph**  
 Precision Hardware  
 a Division of Stanley Security Solutions, Inc.  
 www.stanleysecuritysolutions.com