


Select, mark, and drill holes

- 1 Refer to the *Holes by Function* table and the figure below to determine the holes to be drilled for the lock function and trim combination.
- 2 Determine the inside and outside, hand, and bevel of the door.
- 3 Position one of the door edge templates on the door, making sure that the lock case mortise shown on the template aligns with the mortise pocket prepared in the door. Tape the template to the door.
Note: For metal doors, see the *Q03 Template* (T82603).
- 4 Using the centerlines on the door edge template as a guide, position the appropriate door template on each side of the door. You need to take the bevel into account. Tape the templates to the door.
- 5 Center punch the appropriate drill points.
- 6 Drill the holes. See the *Installation Instructions for Wi-Q™ Mortise Locks*.



Not to scale

Holes by Function

Holes to drill	Functions	
	DV	TV
	I/S	O/S
A Forged trim (2 holes)	Through door	Through door
B Harness (1 hole only)	Through door	Through door
C Cylinder †		■
D Sensor & motor wir* (2 holes) †	■	
F Thumb turn †		■
G Trim mounting (2 holes) †	Through door	Through door
H Lever †	Through door	Through door
J Door sensing channel		TBD

† Because these holes pass through the mortise pocket, it is recommended that each hole be drilled separately rather than straight through.

Title Installation Template for 45HQ Stanley® Wi-Q™ Technology Mortise Locks				BEST ACCESS SYSTEMS			
Series 45HQ	Backset 2 3/4"	Trim style MS, DV, PH, PM	Door thickness 1 3/4"	Rev date 7/2008	Template number Q06	Rev A	

To ensure accurate door preparation, use only factory-generated templates. Do not use copies or facsimilies. T82606/Rev A 0000000 ER-7991-42 July 2008



