

1 Tape the template to the **outside** of the door, aligned with the centerlines.

2 Drill all applicable holes completely through the door (note the exception for the cylinder hole with a mortise device).

Note: Drill holes through device shim if using one.


→
Door edge

↑
Vertical centerline

Battery bracket hole



Ø 7/16"



Ø 7/8"

Ø 1"x1-3/4" deep from door edge

Battery bracket/harness hole

ONLY FOR VON DUPRIN VERTICAL ROD DEVICES OR RIM DEVICES WITHOUT RQE:

Door sensing switch mounting hole



Ø 7/16"




Ø 7/16"

Escutcheon mounting holes (4 places)

These holes align to the Von Duprin lock stile case 'A' holes.

← verify exactly 1" →
↑ verify exactly 1" ↓
Measure scale after printing

Cylinder hole



Ø 2"

Horizontal centerline

←
To hinge

ONLY FOR VON DUPRIN RIM WITH RQE:

Door sensing switch mounting hole & channel

Ø 3/4" wide

Ø 7/16"

Ø 1"x1-3/4" deep from door edge

Lift finger slot

This slot aligns to the Von Duprin lock stile case 'C' hole.

Ø 7/16" channel



Ø 7/16"



Ø 7/16"

Use with Von Duprin LHRB applications only

Title Installation Template for Wi-Q Technology™ EXQ Exit Hardware Trim for Use with Von Duprin 98/99 Series Exit Devices				BEST ACCESS SYSTEMS			
Series EXQ	Backset NA	Trim style MS, PH, PM, DV	Door thickness 1 3/4"–2 1/4"	Rev date 12/2008	Template number Q07	Rev B	

Note: To ensure accurate door preparation, use only factory-originated templates. Do not use copies or facsimiles.


T82607 Rev B 3108638 ER-7991-30 Dec 2008

←
Door edge

↑
Vertical centerline

- 1 Tape the template to the **outside** of the door, aligned with the centerlines.
- 2 Drill all applicable holes completely through the door (note the exception for the cylinder hole with a mortise device).

Note: Drill holes through device shim if using one.



Battery bracket hole

Battery bracket/harness hole

ONLY FOR VON DUPRIN VERTICAL ROD DEVICES OR RIM DEVICES WITHOUT RQE:
Door sensing switch mounting hole & channel

Escutcheon mounting holes (4 places)

These holes align to the Von Duprin lock stile case 'A' holes.

← verify exactly 1" →
↑ verify exactly 1" ↑
Measure scale after printing

→
To hinge

Cylinder hole

Horizontal centerline →

ONLY FOR VON DUPRIN RIM WITH RQE:
Door sensing switch mounting hole & channel

Lift finger slot
This slot aligns to the Von Duprin lock stile case 'C' hole.

Use with Von Duprin RHRB applications only